

Analog/Digital & Serial/Parallel

Communication and Connection



Content

Analog/Digital and Serial/Parallel

Analog / Digital

- Basics of Analog and Digital
- ADC / DAC Ports

Parallel / Serial

- Basics of Parallel and Serial
- Comparison

Example — 7-Segment-Display and Shift Register



Analog / Digital

Communication and Connection

Analog / Digital

Communication and Connection




23:59:59



Analog / Digital


Communication and Connection

ANALOG



Values between e. g. 0 V and 3,3 V

DIGITAL



Only discrete values (1/0 :: ON/OFF :: HIGH/LOW)

Analog / Digital

Communication and Connection


ANALOG

Most of the electronic components are inherently analog

- Resistors, capacitors, diodes, transistors, ...
- Sensors like temperature, humidity, ...

DIGITAL

ESP works internal only with digital values.



Analog / Digital – ADC and DAC

Communication and Connection

ESP works internal only with digital values.


→ Analog values needs to be converted.

ADC – Analog to Digital Converter (ADC1 und ADC2)

- 16 ADC Pins - Input
- 12 Bit Resolution -> Value between 0-4095
- ADC2 can only be used if no Wifi has been started


DAC – Digital to Analog Converter

- 2 DAC Pins (25 and 26) - Output
- 8 Bit Resolution -> Value between 0-255



Serial / Parallel


Communication and Connection




Serial / Parallel

Communication and Connection

PARALLEL



SERIAL



Serial / Parallel - Comparison

Communication and Connection

PARALLEL

- 8 bits transferred at one clock pulse.
- Fast in comparison to serial

Is used when:

- large amount of data is being sent
- the data being sent is time-sensitive
- the data needs to be sent quickly

SERIAL

- One bit at one clock pulse.
- Slow in comparison to parallel
- Less noise and more reliable

Is used when:

- there is a long distance


* geeksforgeeks, „Difference between Serial and Parallel Transmission“. <https://www.geeksforgeeks.org/difference-between-serial-and-parallel-transmission/> , Accessed, 30. Apr 2021

* TechDifferences, „Difference between Serial and Parallel Transmission“. <https://techdifferences.com/difference-between-serial-and-parallel-transmission.html>, Accessed, 01. May 2021

* TotalPhase, „What are the Differences Between Serial and Parallel Communication?“. <https://www.totalphase.com/blog/2020/10/differences-between-serial-parallel-communication/>, Accessed, 04. May 2021

Serial / Parallel - Comparison

Communication and Connection



* geeksforgeeks, „Difference between Serial and Parallel Transmission“. <https://www.geeksforgeeks.org/difference-between-serial-and-parallel-transmission/> , Accessed, 30. Apr 2021

* TechDifferences, „Difference between Serial and Parallel Transmission“. <https://techdifferences.com/difference-between-serial-and-parallel-transmission.html>, Accessed, 01. May 2021

* TotalPhase, „What are the Differences Between Serial and Parallel Communication?“. <https://www.totalphase.com/blog/2020/10/differences-between-serial-parallel-communication/>, Accessed, 04. May 2021

Example



Communication and Connection



Example

Communication and Connection

7 Segment Display with Shift Register



Example


Communication and Connection

Serial to Parallel Shifting

- With shifting register **74HC595**
- 3 Inputs and 8 Outputs


Usage

- To less ports
- Seven Segment Display or 8 LEDs




Example

Communication and Connection




Example

Communication and Connection




Example

Communication and Connection




Example

Communication and Connection




Example

Communication and Connection




Example

Communication and Connection



Example


Communication and Connection



Example

Communication and Connection

Serial to Parallel Shifting




Example - Code

Communication and Connection

```
#include <Arduino.h>
```

```
int dataPin = 15; // Pin to DS of 74HC595 (Pin14)  
int latchPin = 2; // Pin to ST_CP of 74HC595 (Pin12)  
int clockPin = 4; // Pin to SH_CP of 74HC595 (Pin11)
```

```
byte num[] = {  
    B00111111, // 0  
    B00000110, // 1  
    B01011011, // 2  
    B01001111, // 3  
    B01100110, // 4  
    B01101101, // 5  
    B01111101, // 6  
    B00000111, // 7  
    B01111111, // 8  
    B01101111, // 9  
};
```



Order: DP G F E D C B A

Example - Code

Communication and Connection

```
void setup()
{
    // set pins to output
    pinMode(latchPin, OUTPUT);
    pinMode(clockPin, OUTPUT);
    pinMode(dataPin, OUTPUT);
}
```

```
void loop()
{
    for (int i = 0; i < 10; i++)
    {
        writeData(~num[i]); // Send data
        delay(1000);
        writeData(0xff);    // Clear display
    }
}
```


Example - Code

Communication and Connection


```
void writeData(int value)
{
    // Set latchPin low
    digitalWrite(latchPin, LOW);

    // Send serial data
    shiftOut(dataPin, clockPin, LSBFIRST, value);

    // Set latchPin to high
    digitalWrite(latchPin, HIGH);
}
```

Example

Communication and Connection





Thank You!

Analog/Digital & Serial/Parallel